DITIC

AD-A286 869

COLLECTION AND ANALYSIS OF ACOUSTIC DOPPLER CURRENT PROFILER DATA

Final Technical Report

by
W R Roy Richardson & Colin R Thorne
The University of Nottingham
September 1995 - January 1996

United States Army
EUROPEAN RESEARCH OFFICE OF THE U.S. ARMY
London England

CONTRACT NUMBER: R & D 7791-EN-09

Approved for Public Release: distribution unlimited

The Research reported in this document has been made possible through the support and sponsorship of the U.S. Government through its European Research Office of the U.S. Army. This report is intended for the internal management use of the University of Nottingham and U.S. Government.

SUMMARY

Acoustic Doppler Current Profilers are presently employed by the U.S. Army in a number of projects. However, as with most new techniques there have been several problems both with the collection and the subsequent analysis of data. The main objective of this work is to improve the accuracy of Acoustic Doppler Current Profilers by examining the existing survey techniques and by developing computer software to process survey data. Two FORTRAN programs have been developed during the contract period. One program is designed to combine data from an external differential global positioning system with data from an ADCP to give a more reliable discharge measurement, and the second program is designed to in-fill gaps in records due to missing ADCP velocity data. In order to test and develop the software, data was collected on the Columbia River, Washington. This document details the resulting software designed and briefly reports on the fieldwork undertaken.

CONTENTS

	page number
I	CONVERSION CONSTANTS
П	LIST OF SYMBOLS
Ш	LIST OF FIGURES (iii)
1. IN'	TRODUCTION
2. PR	OJECT CHRONOGRAPHY
	2.1 ITINERARY (3)
	2.2 DATA COLLECTION
	2.3 RESULTS(5)
3. GF	PSQ
	3.1. INTRODUCTION
	3.2. METHOD
	3.2.1 DGPS Data Processing
	3.2.2 Velocity Correction
	3 2.3 Discharge Calculation
4. AI	DCPFILL: Filling in Bad or Missing Velocity Data
	4.1. INTRODUCTION(17)
	4.2. METHOD
5. CO	ONCLUSIONS & RECOMMENDATIONS (20)
6. RI	EFERENCES (22)
APP:	ENDIX A: ADCP ASCII Output Format
APP	ENDIX B: G.'SQ ver 1.0 SOURCE CODE
APP	ENDIX C: ADCPFILL SOURCE CODE
APP	ENDIX D: GPSQ ver 1.0 USER MANUAL
A DD	ENDLY E. ADCDELL LICLD MAGILIAL

I. CONVERSION FACTORS FOR MEASUREMENT UNITS

Because of the parties involved in this research project, namely The University of Nottingham, UK, and the United States Government, a table of conversion factors for Imperial and SI units is given below:

FROM	ТО	MULTIPLY BY
Inches (in)	Millimetres (mm)	25.4
Feet (ft)	Metres (m)	0.3048
Square Feet (fl ²)	Square Metres (m²)	0.0929
Cubic Feet (ft³)	Cubic Metres (m³)	0.02832
Yards (yd)	Metres (m)	0.9144
Miles (Mi)	Kilometres (km)	1.609
Millimetres (mm)	Inches (in)	0.0394
Metres (m)	Feet (ft)	3.281
Square Metres (ni ²)	Square Feet (ft²)	10.7639
Cubic Metres (m³)	Cubic Feet (ft²)	35,3147
Metres (m)	Yards (yd)	1.0936
Kilometres (km)	Miles (Mi)	0.621

II. LIST OF SYMBOLS

Е	Corrected Easting
N	Corrected Northing
e	GPS Easting
n	GPS Northing
m	Survey line gradient
c	Survey line intercept
β	Local magnetic declination
ρ	True ADCP direction
Ψ	Measured ADCP direction
\mathbf{V}_{w}	Absolute water velocity
$V_{\scriptscriptstyle B}$	Boat velocity
V_{ADCP}	ADCP measured water velocity
R	ADCP range
$\mathbf{D}_{\mathbf{n}}$	Ensemble depth
$\mathbf{D}_{\mathtt{ADCP}}$	ADCP transducer depth
θ	ADCP transducer beam angle
U	Velocity at height Z above bed
\mathbf{U}^*	Shear velocity
$\mathbf{Z}_{\mathbf{o}}$	Bottom roughness height
b	Power Law exponent
a'	Non-ADCP parameters in the power law equation
Q_{top}	Top layer discharge
W	Corrected ensemble width
\mathbf{D}_{blank}	Blank depth
\mathbf{Q}_{bin}	Bin discharge
V	Corrected velocity magnitude
α	Survey line direction

Near shore discharge

Bottom layer discharge

Nearest ensemble depth averaged velocity

 $egin{array}{ll} D_m & & \mbox{Nearest ensemble depth} \ X_i & & \mbox{Vector cross product} \ \end{array}$

Bin size

h, Bin height

H

 Q_{burn}

 Q_{thore}

 $V_{\mathfrak{m}}$ L

 $\begin{array}{lll} \Delta t & \text{Time elapsed during ensemble} \\ E_{boat} & \text{East velocity of the survey vessel} \\ N_{boat} & \text{North velocity of the survey vessel} \end{array}$

 $\begin{array}{ll} E_{\text{water}} & \quad East \ \text{velocity of the water} \\ N_{\text{water}} & \quad North \ \text{velocity of the water} \end{array}$

III. LIST OF FIGURES

- Plate 1. Test Site on Columbia River, Washington
- Figure 1.1 Location Map of Test Data Site, Bonneville Dam, Columbia River, Washington.
- Figure 1.2 Measured velocities (it/s); (a) 'Bottom-track' referenced and (b) GPS referenced

1. INTRODUCTION

Acoustic Doppler Current Profilers (ADCPs) are "state-of-the-art" instruments that measure water velocities acoustically, in particular the Doppler effect. The Doppler effect is the change in observed sound pitch that results from relative motion between a source and observer. The major advantages of ADCPs over more traditional methods of river survey are their speed of use, quality of data, resolution of measurement and their ability to be used onboard moving vessels to measure river discharges (Didden, 1989)

However, due to their nature of operation ADCPs produce large quantities of data that requires extensive post-survey processing in order to be converted into a usable format. Additionally when being used onboard a moving vessel and under certain conditions (i.e. high flows) their ability to "bottom-track" breaks down (Münchow et al., 1995). The ADCP records the velocity of the channel bed as well as the water velocity and makes a correction for vessel motion during measurement. In order to overcome this "bottom-track" problem new survey techniques and post-survey data processing software have been designed. The "bottom-track" facility is replaced by an external Differential Global Positioning System (DGPS) to monitor and record vessel motion.

During this study test data sets were collected using an ADCP in conjunction with a DGPS to measure water velocities and river discharge on the Columbia River, upstream and downstream of the Bonneville Dam, Washington. GPSQ a DOS based FORTRAN computer software package was then developed to combine the data files from the ADCP with the files recorded from the DGPS.

In addition to the "bottom-track" problem, ADCP data can be prone to missing ensembles in a given cross-section. These missing data give rise to accumulated errors in discharge and

positioning data when the ADCP is being used in a standard mode (i.e. without an external DGPS). During this study a second DOS based FORTRAN program (ADCPFILL) was developed to fill-in missing data.

2. PROJECT CHRONOGRAPHY

2.1 ITINERARY

1ST September 1995:

Mr Richardson and Prof. Thorne arrived in Vicksburg, Mississippi. After initial meetings Mr Richardson began work at Waterways and met with Mike Trawle, Tim Fagerburg and Thad Pratt to outline possible areas of concern with present ADCP data collection techniques and analysis.

2nd September to 30th September 1995:

Bottom-track errors were highlighted as a major problem in the ADCP river gauging technique, and subsequently Mr Richardson began developing a method for calculating discharge using a Differential Global Positioning System to replace bottom-track. He also started designing general code for GPSQ software.

1st October to 14th October 1995:

Field work in Washington, on Columbia River. Mr Richardson and Thad Pratt collected sample data sets necessary for software development and refined survey methods for collecting and logging DGPS data.

16th October to 1st November 1995:

Mr Richardson and Thad Pratt returned to Vicksburg to refine and complete software development for GPSQ. Problems of missing ADCP data in all ADCP applications became apparent - ADCPFILL was designed to overcome this.

2nd November 1995:

Mr Richardson returned to U.K.

2.2 DATA COLLECTION

In order to overcome the inherent bottom-track problem within the ADCP setup, an alternative to bottom-tracking must be utilised to monitor boat motion. An ideal alternative is a Differential Global Positioning System (DGPS). A DGPS achieves reasonable accuracy in absolute position and it is also capable of greater precision when monitoring relative positions or velocity (FAP24¹, 1993)

A trial data set was collected on the Columbia River, Washington upstream and downstream of the Bonneville Dam. Data was collected using an RDI Instruments ADCP with an acoustic frequency of 600 kHz in conjunction with a Trimble Navigations DGPS. A test data set was needed for a number of reasons. First, it was necessary in order to develop the software required for the subsequent corrections applied to the raw ADCP data. Second, the technique of using a DGPS in conjunction with an ADCP for gauging discharge required verification. Finally, a survey method for setting up and logging data from the DGPS was required.




Plate 1. Test Site on Columbia River, Washington




Figure 1. Location Map of Test Data Site, Bonneville Dam, Columbia River, Washington.

2.3 RESULTS


Figure 1.2 shows results obtained at one cross-section during the test survey downstream of Bonneville Dam. Figure 1.2(a) shows results from the ADCP used in bottom-track mode, with a discharge calculated of 130143 cfs. Figure 1.2(b) shows results obtained using the ADCP in conjunction with the DGPS, with a discharge calculated using 'GPSQ' of 191750 cfs. It is obvious from the plots of measured velocities in figure 1.2 that the velocity field shown is significantly

different dependent on the velocity reference used. Also, the discharge calculated using the DGPS as a velocity reference is 47% greater than that when using bottom-track. The 'bottom-track declination' calculated by 'GPSQ' at the time of data processing is 21 degrees (the bottom-track declination is the difference between the survey line direction calculated using bottom track data and the survey line direction calculated using the DGPS data).

The discharge results may be explained in part by the theory that bottom-track errors lead to an under-estimation of the water velocities and therefore discharge, through an under-estimation of vessel velocity. The bottom-track declination of 21 degrees may be partly due to very localised magnetic affects on board the survey vessel interfering with the internal ADCP compass. This affects the measurement of velocities in two ways. First, the bottom track measurement of the vessel's speed and direction is affected. Second, the measurement of water velocities made relative to the ADCP is affected. When these two measurements are combined to calculate an absolute water velocity, the affect of local magnetic declination is compounded. The DGPS is not susceptible to the affects of local magnetic declination and can therefore eliminate the affect from the measurement of vessel velocity.

ં

9



discharge: 130143 cfs




Figure 1.2 Measured velocities (fi/s); (a) 'Bottom-track' referenced and (b) GPS referenced

3.1 INTRODUCTION

When ADCPs are used on board moving vessels for river discharge measurements, they are generally configured to record the velocity of the bed (bottom track) and the velocity of the water relative to the ADCP. The ADCP then combines the two velocities to give an absolute water velocity. Under certain conditions ADCP bottom track data can become unreliable and thus introduce errors into the measurement of water velocities and discharge. ADCP bottom track is limited by the convex arrangement of the ADCP transducer heads, making it impossible for the ADCP to measure the entire water column. When the ADCP is measuring what it assumes to be the bottom, it is in fact measuring a moving surface of wat-/sediment just above the bed. Under normal conditions the echo from the hard bottom surface is enough to overcome this problem, but under higher flow conditions, when sediment is being entrained into the water and the bed is mobile, errors are introduced. Generally, bottom track errors of this nature will lead to an underestimation of the discharge due to the ADCP using a velocity reference that is moving in the downstream direction.

'GPSQ' is a DOS based program written in FORTRAN which, together with an amended survey technique, will re-calculate ADCP measured velocities and discharge. It does this by utilising data from an external differential global positioning system (DGPS), to replace bottom track and measure boat motion. GPSQ uses ADCP velocity data that is taken from the RDI-TRANSECT program, in the usual ASCII processed data format, with the velocity reference set to "none". DGPS files are then combined with the ADCP ASCII files to correct for boat motion and produce correct velocities and discharge.

3.2 METHOD

GPSQ works in three modules. The program modules are:

- (1) DGPS data processing module
- (2) Velocity data correcting module
- (3) Discharge calculating module

3.2.1 DGPS Data Processing

The first module of GPSQ reads the GPS navigation file and calculates the boat motion and position for each ADCP ensemble. The module will read GPS data in the following format;

ENSEMBLE 1038 PCTIME 4685248 10:01:56 1624658.61 718868.14 10:01:57 1624656.07 718866.96 10:01:58 1624654.36 718866.70 10:01:59 1624652.71 718867.11

ENSEMBLE 1039 PCTIME 4685605 10:02:00 1624651.46 718868.14 10:02:01 1624650.64 718869.64 10:02:02 1624649.27 718871.14 10:02:03 1624648.40 718873.53 10:02:04 1624648.40 718873.53

ENSEMBLE 1040 PCTIME 4686034 10:02:05 1624647.33 718876.20 10:02:06 1624646.06 718878.92 10:02:07 1624644.58 718881.78 10:02:08 1624642.61 718885.42

The ensemble header line gives an ensemble number followed by an ensemble start time (PCTIME) in hundredths of a second. The GPS data lines give a position time (hours:minutes:seconds) followed by an Easting and Northing. The GPS data processing module reads this file into an array of ensemble number with PCTIME from the end of the ensemble to

the start of the transect, and an array of GPS East and North with time from the start of the first ensemble. The two arrays are then matched in terms of time to give each ensemble number a position at the end of the ensemble and an average boat velocity during the ensemble (a velocity is calculated for each GPS record and then averaged over the ensemble period).

The next segment of this module then calculates a survey line definition based on the GPS data. The start and end points of the GPS record are used as the start and end points for the survey line. A definition of the survey line is necessary for the discharge calculation method described below. A distance along the survey line (course made good; CMG) and a width is calculated for each ensemble, together with a corrected position. GPS positions are then translated to survey line positions using the following equations:

$$E = (m.n + e - c.m) / (m^2 + 1)$$
 (Eqn 3.1)

N
$$\approx$$
 m. E+c (Eqn 3.2)

where:

E = Corrected Easting

N = Corrected Northing

e = GPS Easting

n == GPS Northing

m Survey line gradient (dist. North / dist. East)

c Survey line intercept

The output of the GPS processing module is in the format shown below, Velocities and course made good data are given in the selected data output units, US customary or SI. The GPS processed data file is a temporary file which is removed at the end of the program execution.

ENS	CMG	EASTING	NORTHING	E VEL	N VEL	WIDTH
1038	2.96	1624658,00	718868.90	5.81	-5.33	1.43
1039	18.76	1624656.00	718873.20	25.93	-3.69	5.67
1040	52.84	1624651.00	718882.40	42.18	-5.20	9.05
1041	98.75	1624645,00	718894.80	49.46	-6.25	9.54
1042	155.82	1624636 00	718910.16	64.82	-7.35	9.78
1043	206.34	1624629.00	718923.7 0	36.06	-7.48	9.68
1044	252.05	1624623.00	718936.00	55.45	-5.97	10.25
1045	313.51	1624614.00	718952.60	67,55	-5.54	11.29

3.2.2 Velocity Correction

The next module in GPSQ takes the processed GPS data and combines it with the processed ADCP ASCII data, to give corrected water velocities. The ADCP processed ASCII files are in the format shown in Appendix A.

For each measurement bin the measured velocity direction is corrected for the local magnetic declination (β) as input by the user.

$$\beta = \rho - \psi \qquad (Eqn \ 3.3)$$
 where:
$$\beta = Docal \ magnetic \ declination$$

$$\rho = True \ ADCP \ direction$$

ψ · Measured ADCP direction

The non-referenced East and North ADCP velocities and then corrected for boat motion to give an absolute water velocity.

V_w Absolute water velocity

 $V_{\rm B}$ = Boat velocity given by DGPS

 $V_{AIX'P}$ = ADCP non-referenced measured water velocity

A depth is calculated for each ensemble using either ADCP beam depth data given in the ADCP ASCII file, or external fathometer depth data in a format as yet untested in the field. The ensemble depth is used to calculate an ADCP range. Velocity data outside of this range is discarded. The range of acceptable ADCP data is given by the following equation:

$$R = (D_n - D_{AlXP}) \cdot \cos\theta \cdot \dots \cdot (Eqn 3.5)$$

where:

R = ADCP range

 $D_n = Ensemble depth$

 D_{AIXP} = ADCP transducer depth (given in ADCP ASCII file)

0 = ADCP transducer beam angle (INPUT by user)

The output from the velocity data correction module is given in the file VELOCITY.DAT which is created in the working directory. VELOCITY.DAT is in the following format:

	id, cns,	dist,	cast,	north,	width,	depth,	bin,	mag,	dim,	cast,	north,	vert,	erros	, db ave	, adep range
	1 1038	2.97	1624658.00	718858.90	5.81	24.92	5.00	5.61	297.30	-4.99	2.57	.00	-1.70	247.25	43.48
	1 1038	2.97	1624658.00	718868,90	5.81	24.92	6.70	5.49	288.80	-5.20	1.77	10	-,60	235,50	23,48
	1 1038	2.97	1624658.00	718868.90	5.81	24.92	8.30	5.19	282.71	-5.06	1.14	.00	40	206.25	23.48
ļ	1 1038	2.97	1624658.00	718868.90	5.81	24.92	9.90	5.37	277,87	-5.32	.74	20	-,60	180.25	23.48
l	1 1038	2.97	1624658.00	718868.90	5.81	24.92	11.60	4.52	282.69	-4.41	.99	.10	-,10	172.50	23,48
1	1 1038	2.97	1624658.00	718868.90	5.81	24.92	11.20	5.25	291.11	-4.90	1.89	.20	20	163.00	23.48
	1 1038	2.97	1624658.00	718868.96	5.81	24.92	14.90	5 46	290.98	-5.10	1.95	20	70	159,25	23.48
	1 1038	2 .97	1624658.00	718868.90	5.81	24.92	16.50	5.65	297.86	4.99	2.64	.10	90	153.50	23.48
	1 1038	2 97	1624658.00	718868.90	5.81	24.92	18.10	5,86	303.79	-4.87	3.26	20	.00	150.50	23,48
ł	1 1038	2.97	1624658.00	718868.90	5.81	24.92	19.80	5.14	289.47	-4.85	1.71	- 10	10	165.50	23,48
	2 1039	18.77	1624656.00	718873.20	25.94	25 50	5.00	5.25	307.51	-4.17	3.20	.20	10	211.00	24.02
	2 1039	18.77	1624656.00	718873.20	25.94	25,50	6.70	5.42	304.90	-4,45	3.10	.10	.10	204.75	24.02

Any bad bins of measurement within the ADCP range are ignored and are not recorded in the corrected velocity file.

3.2.3 Discharge Calculation

A discharge is calculated based on the survey line defined by the GPS data. Each ensemble is assigned a width and position along the survey line and a discharge is calculated through the ensemble. For each ensemble a top layer discharge (estimated), middle layer discharge (measured) and a bottom layer discharge (estimated) are calculated. Two options are available for the top layer discharge estimation, the power or constant method. The missing bottom layer discharge is calculated using the power method.

TOP LAYER DISCHARGE ESTIMATION USING THE POWER METHOD

The power law equation for describing velocity profiles in open channels (Chen, 1991: Simpson & Oltmann, 1990) is given as:

$$U/U^* = 9.5 \cdot (Z/Z_0)^b$$
 (Eqn 3.6)

where:

U = Velocity at height Z above the bed

U* = Shear velocity

Z Height above channel bed

 Z_0 = Bottom roughness height

• Power Law exponent

which can be re-arranged to give:

$$U = (9.5 \cdot U^* / Z_e^b) \cdot Z^b \cdot \dots (Eqn 3.7)$$

$$a' = (9.5 \cdot U^* / Z_0^b) \dots (Eqn 3.8)$$

where a' represents the non-ADCP parameters, then

$$U = a' \cdot Z^b \dots (Eqn 3.9)$$

For each measurement bin, GPSQ solves equation 3.9 to give a value of a'. Within each ensemble the a' values are averaged (a'_avg), and the average is then used to solve for the missing top layer velocity. The top layer discharge is then given by;

$$Q_{top} = a'_avg \cdot Z^b \cdot W \cdot D_{blank} \cdot \dots \cdot (Eqn 3.10)$$
 where:

 Q_{ton} = Top layer discharge

W = Corrected ensemble width

 $D_{blank} = Blank depth$

TOP LAYER DISCHARGE ESTIMATION USING THE CONSTANT METHOD

The constant method for estimating the missing discharge near the surface is the simpler of the two techniques. The constant method does not follow accepted hydraulic principles of velocity profile description, however, under certain circumstances it seems to give a more accurate picture of near surface properties. The method simply takes the velocity from the first good measurement bin in the profile (V_{top}) and extrapolates to the surface.

MIDDLE LAYER MEASURED DISCHARGE

The discharge through each measurement bin is given by the following equation:

$$Q_{bin} = V \cdot cos(\alpha - \rho) \cdot W \cdot H \cdot \dots (Eqn 3.12)$$

where:

 Q_{bir} = Bin discharge

V = Corrected velocity magnitude

α = Survey line direction

 ρ = Corrected velocity direction

H = Bin size

The bin size (H) is equal to the distance between the bin being considered and the last good measurement bin. This is usually equal to the configured bin size but will change if any bins are missing due to bad data. The middle layer discharge is then equal to the sum of all measurement bin discharges.

BOTTOM LAYER ESTIMATED DISCHARGE

The missing discharge outside of the ADCP range at the bottom of the velocity profile is calculated using the power law equation (Eqn 2.5). The bottom layer discharge is given by:

$$Q_{btm} = a'_a avg \cdot ((D_n - R) / 2)^b \cdot (D_n - R) \cdot W \cdot ... (Eqn 3.13)$$

where:

 Q_{btm} = Bottom layer discharge

NEAR SHORE DISCHARGE ESTIMATION

GPSQ can be used to estimate any discharge that is not measured close to the banks at the beginning and end of each transect. GPSQ uses the same ratio-interpolation method employed by TRANSECT to estimate near shore discharge. The method uses the first and last known velocities and assumes a tri-angular area between the bank and transect. The missing near shore discharges are given by:

$$Q_{\text{shore}} = 0.707 \cdot V_{\text{m}} \cdot L \cdot D_{\text{m}} / 2 \cdot ...$$
 (Eqn 3.14) where:

 Q_{shore} = Near shore discharge (start or finish)

 $V_{\rm m}$ = Nearest ensemble depth averaged velocity

L = Distance to bank

 D_m = Nearest ensemble depth

The total discharge for the transect is then given by the sum of the top layer discharges, measured discharges, bottom layer discharges and the near shore discharges. The discharge output file, whose name and location is specified by the user, is in the following format:

```
top layer discharge estimation mothod; power power eo-efficient = 1.667000E-01 cusemble, dist, easting, northing, width, depth, bin q, top q, btm q, total q = 1038 | 2.97 | 1624658.00 | 718868.90 | 5.81 | 24.92 | -336.10 | -95.60 | -18.51 | -450.21 | -2.34 | = 1039 | 18.77 | 1624656.00 | 718873.20 | 25.94 | 25.50 | -939.54 | -263.17 | -52.39 | -1255.10 | -1.43 | = 1040 | 52.84 | 1624651.00 | 718882 | 40 | 42.18 | 30.50 | -2363.18 | -547.49 | -130.89 | -3041.56 | -1.78 | = 1041 | 98.74 | 1624645.00 | 718894.80 | 49.46 | 37.93 | -4173.16 | 688.66 | -204.95 | -5066.76 | -1.83 | = 1042 | 155.83 | 1624636.00 | 718910.10 | 64.82 | 44.30 | -7750.86 | -1012.12 | -354.03 | -9117.00 | -2.00 | = 2.00 | = 1041 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 1040 | = 10
```

4. ADCPFILL

4.1 INTRODUCTION

ADCPFILL is a DOS based program which will read processed ADCP files from the RDI TRANSECT program and write over bad ensemble data. Bad ensemble data will occur when two or more ADCP transducer beams do not return good data for any reason. Bad ensemble data affects the overall calculation of discharge and the ability of the ADCP to calculate the position of each ensemble, in terms of distance travelled, displacement east and north and straight line distance to starting point (course made good). Therefore, after one bad ensemble the bottom track and discharge data for every subsequent ensemble has a built-in error, which accumulates after every bad data segment.

4.2 METHOD

During playback of raw ADCP files, an ASCII file can be produced (using the ALT-A command) containing position and velocity/discharge data for each ensemble. This ASCII file contains a header followed by velocity data for each ensemble in the transect. The ensemble header contains the time at the start of the ensemble, bottom track data, depth data for each transducer beam, discharge data and various other survey parameters (see appendix A). The discharge data contained in the ensemble header can be used as a test for bad segments of ensembles. Bad ensembles show no increment in the measured discharge, whereas good ensembles show an increase in the cumulative discharge measurement.

Bin data for the ensemble is then given in the form of depth, velocity magnitude, velocity direction, east velocity, north velocity, vertical velocity, error velocity, echo intensities, percentage good data (based on the number of beams used in the solution of the equation of motion of the water) and bin discharge. For bad bins of measurement, data values of -32768 are

attributed to velocities and 2147483647 are attributed to discharge. Bad measurement bins are the result of either the bin being outside the ADCP range or more than one beam returning a bad signal from that particular range of depths.

Once bad ensembles have been identified, ADCPFILL uses a simple linear interpolation to re-calculate ensemble bottom track data, beam depths, pitch, roll, corrected heading, ADCP temperature, bin velocity, echo intensities and percentage good data. Discharge data is not filled by interpolation, but calculated separately. Ensemble time and number are not affected by bad velocity measurements and, therefore, do not need recalculating. ADCPFILL uses the following equation to interpolate between good ensembles:

$$k_i = k_1(n_2-n_i) + k_2(n_i-n_1) / (n_2-n_1)$$
 where:

k = Parameter under consideration

n = Ensemble number

= Bad ensemble

Last good ensemble before bad data segment

Next good ensemble after bad data segment

Once the bottom track and velocity data for each bad ensemble has been corrected, the bin and ensemble discharges can then be re-calculated. ADCPFILL uses the same moving boat method of discharge calculation employed by TRANSECT (Simpson and Oltmann, 1990; Gordon, 1989). The discharge for any given measurement bin is calculated as follows:

$$Q_{bin} = X_i \cdot h_i \cdot \Delta t \cdot \dots (Eqn 4.2)$$

where:

 Q_{bin} = Bin discharge

 $X_i = Vector cross product$

h_i - Bin height

 Δt = Time elapsed during ensemble

The vector cross product (X_i) is given by the following formula:

$$X_i = (E_{boat} \cdot N_{water}) - (N_{boat} \cdot E_{water}) \cdot \dots (Eqn 4.3)$$

where:

 E_{boat} = East velocity of the survey vessel

 N_{boat} = North velocity of the survey vessel

 E_{water} = East velocity of the water

 N_{water} = North velocity of the water

The accumulated errors in measured discharge and bottom track data are calculated for each bad segment of ADCP data and then added to subsequent ensembles to correct for accumulated errors.

The final output of ADCPFILL is in the same format as the original ADCP data file, and as such can be used by other software packages designed for ADCP ASCII data. The numbers of any bad ensembles corrected are displayed on the screen at the time of processing.

5. CONCLUSIONS & RECOMMENDATIONS

At conception, this project was designed to address the general problem of ADCP data management and analysis on the Mississippi River, in particular to outline the basis for a usable engineering database of ADCP data. However, under certain flow conditions a more fundamental problem was identified, that of actually collecting good quality data using the ADCP. Using experience gained working in Bangladesh with ADCPs on the Brahmaputra River, a new survey and data processing technique was designed and tested.

In the main body of this report two computer programs are detailed, GPSQ and ADCPFILL, which were developed during the study to overcome two of the basic problems of ADCP data collection, bottom-track errors and blank or missing data. These programs were validated and found to work well with the sample data collected on the Columbia River, however they require further development in order to be more flexible for general use and eventually to be incorporated into a standard method of river discharge measurement.

The significant differences between ADCP velocity and discharge data collected using bottom tracking and DGPS, would seem to pose more questions then they answer. Additional work is needed analysing the data collected during the test survey, in particular looking at the affects of local magnetic declination and the possible incorporation of a gyro compass into the survey method.

Further improvements to the survey methods could be achieved through the addition of an external fathometer gauge to measure cross-sectional bathymetry. This would require further software development and field testing. At present depth data is obtained from the ADCP beams, a fathometer would give a more detailed and accurate measurement, thus improving confidence in the discharge calculation. Further work is also needed on procedures to ensure correct

matching of the differential global positioning system file and the ADCP file, in order to ensure that data taken from the two files are combined accurately in time.

6. REFERENCES

- Chen, Cheng-Lung (1991), "Unified Theory on Power Laws for Flow Resistance". Journal of Hydraulic Engineering, Vol 117, No. 3, March 1991, pp 371-389
- Chereskin, TK, and Harding, J (1993), "Modelling the performance of an Acoustic Doppler Current Profiler", Journal of Atmospheric Oceanic Technology, Vol. 10, pp 42-63.
- Didden, N (1989), "Performance evaluation of a ship-board 115-kHz ADCP", Continental Shelf Research, Vol. 7, pp 1232-1243
- Gordon, R. L. (1989), "Acoustic Measurement of River Discharge", Journal of Hydraulic Engineering, Vol 115, no. 7, July 1989, pp 925-936
- Münchow, A., Coughran, C. S., Hendershott, M. C., and Winant, C. D. (1995), "Performance and Calibration of an Acoustic Doppler Current Profiler Towed below the Surface",

 Journal of Atmospheric and Oceanic Technology, Vol. 12, April 1995, p435-444
- New, A. L. (1992), "Factors affecting the quality of shipboard ADCP data", Deep Sea Research, Vol. 39, pp. 1985-1992.
- Simpson, M. R. and Oltmann, R. N. (1990), "An Acoustic Doppler Discharge Measurement System", Proceedings of the 1990 National Conference on Hydraulic Engineering, Vol 2, pp 903-908
- FAP24 (1993) "Selection of survey techniques", FAP24 report presented to the International Workshop on 'Morphological Behaviour of the Major Rivers in Bangladesh, Dhaka, November 1993.

APPENDIX A

ADCP ASCII Output Format

Row	Field	Description
1	1 2 3 4 5 6 7 8 9 10 11 12 13	ENSEMBLE TIME — Year (at start of ensemble) — Month — Day — Hour — Minute — Second — Hundredths of seconds ENSEMBLE NUMBER (or SEGMENT NUMBER for processed or averaged raw data) NUMBER OF ENSEMBLES IN SEGMENT (if averaging ON or processing data) PITCH — Average for this ensemble (degrees) ROLL — Average for this ensemble (degrees) CORRECTED HEADING — Average ADCP heading + heading offset - magnetic variation ADCP TEMPERATURE — Average for this ensemble (*C)
2	1 2 3 4 5 6 7 8 9 10 11 12 13	BOTTOM-TRACK VELOCITY — Exst(+)/West(-); average for this ensemble (cm/s or ft/s) - North(+)/South(-) - Vertical (up[+]/down[-]) - Error WATER LAYER VELOCITY — East(+)/West(-); average for this ensemble (cm/s or ft/s) - North(+)/South(-) - Vertical (up[+]/down[-]) - Error DEPTH READING — Beam 1 average for this ensemble (m or ft. as set by user) - Beam 2 - Beam 3 - Beam 4 - Beam 5 (if present)
3	1 2 3 4 5	TOTAL ELAPSED DISTANCE — Through this ensemble (from bottom-track data; in m or ft) ELAPSED TIME — Through this ensemble (in seconds) DISTANCED TRAVELLED NORTH (m or ft, as set by user) DISTANCED TRAVELLED EAST (m or ft, as set by user) COURSE MADE GOOD — Through this ensemble (from bottom-track data)
4	1 2 3 4 5	NAVIGATION DATA — Latitude: average for this ensemble (degrees) — Longitude: average for this ensemble (degrees) — North(+)/South(-) ship movement: average for this ensemble (cm/s or ft/s) — East(+)/West(-) ship movement: average for this ensemble (cm/s or ft/s) — Total distance travelled through this ensemble (cm or ft)
5	1 2 3 4 5 6 7 8 9	DISCHARGE VALUES - Middle part of profile (measured); m³/s or ft³/s - Top part of profile (estimated); m³/s or ft²/s - Bottom part of profile (estimated); m³/s or ft²/s - Start-shore discharge estimate; m³/s or ft²/s - Starting distance (boat to shore); m or ft - End-shore discharge estimate; m³/s or ft³/s - Ending distance (boat to shore); m or ft - Starting depth of middle layer (or ending depth of top layer); m or ft - Ending depth of middle layer (or starting depth of bottom layer); m or ft
6	1 2 3 4 5 6	NUMBER OF BINS TO FOLLOW MEASUREMENT UNIT — cm or ft VELOCITY REFERENCE — BT, LAYER, or NONE INTENSITY UNITS — dB or counts INTENSITY SCALE FACTOR — in dB/count SOUND ABSORPTION FACTOR — in dB/m
7	1 2 3 4 5 6 7 8 10 11 12	DEPTH — Corresponds to depth of data for present bin (depth cell); includes ADCP depth and blanking value; in m or ft. VELOCITY MAGNITUDE VELOCITY DIRECTION EAST VELOCITY COMPONENT — East(+)/West(-) NORTH VELOCITY COMPONENT — North(+)/South(-) VERTICAL VELOCITY COMPONENT — Up(+)/Down(-) ERROR VELOCITY ECHO INTENSITY — Beam 1 — Beam 2 — Beam 3 — Beam 4 PERCENT-GOOD DISCHARGE

العابة عبيسيان

}

APPENDIX B

GPSQ ver 1.0 SOURCE CODE

```
c a title subroutine
    call clearscreen
    write(*, *) '
                             Welcome to GPSQ ver 1.0 for DOS'
    do k=1, 10
     write (*, *)
    enddo
    write (*, *) 'press ENTER to contineo'
    read (*, *)
    call filename
    end
    subroutine filename
c a subroutine for entering adep and navigation input file names
    character*70 adep file, nav file
    call clearscreen
    write(*, *) 'please enter ADCP ascii file name and path'
    write(*, *)
    read(*, '(a70)') adcp_file
    write(*, *)
    call clearscreen
    write(*, *) 'please enter NAVIGATION file name and path'
    write(*, *)
    read(*, '(a70)') nav file
    call clearscreen
    call data out(adep file, nav file)
    end
    subroutine data out(adcp file, nav file)
c a subroutine for selecting the units of measurement for data output
    real units, units2, units3
    integer option4, error
```

```
character*70 ft cm*1, adop file, nav file
   open (4, file = adcp file, status = 'old')
   call clearscreen
  10 continue
   write(*, *) 'OPTIONS FOR DATA OUTPUT....'
   write(*, *)
   write(*, *) '(1) ENGLISH units (ft, ft/s, cfs)'
   write(*, *)
   write(*, *) '(2) SI units (m, m/s, cumecs)'
   do j=1, 10
     write(*, *)
   enddo
   write(*, *) 'please enter an option number'
   read *, option4
  20 continue
c 'units' is a factor used to convert data into the desired output
    select case(option4)
     case(1)
      units = 3.281
     case(2)
      units = 1.0
     case default
      call clearscreen
      write (*, *) 'please re-enter an option number'
      goto 10
    end select
    do 30, j=1, 8
      read (4, 100)
  30 continue
  100 format(70x)
c Adop data file is read to determine the measurement unit 'ft em'
c 'units2' is used to convert the ADCP data into a form whereby
c 'units' can be applied
c 'units3' is req'd because if the measurement unit is S1 then velocity
c data is given in cm not m
    read (4, '(3x, a1)', end=40, err -40, iostat=error) ft crn
    select case(ft cm)
     case('f')
      units2 = units/3.281
      units3 = 1
```

```
case('c')
     units2 = units/1.0
     units3 0.01
   end select
   close (4)
   call q_method(units, units2, units3, adep_file, nav_file)
  40 continue
   if(error .ne. 0)then
     catl clearscreen
     write (*,*) 'CANNOT READ measurement unit'
     write (*,*) 'ERROR in', adep file
     stop
   endif
   end
c a subroutine for entering preference of power or constant method for
e top layer discharge estimation
   subroutine q method(units, units2, units3, adep file, nav file)
   real units, units2, units3
   integer option2
   character*70, adoptile, nav file
   call clearscreen
  10 continue
    write(*, *) 'OPTIONS FOR DISCHARGE CALCULATION....'
    write(*, *)
    write(*, *) '(1) use "POWER" method for top layer estimation'
    write(*, *)
    write(*, *) '(2) use "CONSTANT" method for top layer estimation'
    doj 1, 10
     write(*, *)
    enddo
    write(*, *) 'please enter an option number'
    read *, option2
    select case (option2)
     case(1)
       call discharge (units, units2, units3, adep file, nav file)
```

```
call discharge2(units, units2, units3, adcp file, nav file)
     case default
       call clearscreen
       write (*, *) 'please re-enter option number'
       goto 10
   end select
    end
c a subroutine for calculating discharge using the power method
   subroutine dischargel (units, units2, units3, adep_file, nav_file)
    real depth bin(100), vel mag(100), vel dirn(100), corr w,
   \pm e \ vei(100), n vel(100), z vel(100), db avg(100), depth avg,
   terror vel(100), total bing, toplayer q, btmlayer q,
   +a avg, ensemble q, line grad, blank depth, a(100),
   +power coeff, bin vel(100), bin q(100), adep range(100),
   +bin size, line dira, total1, total2, total3, total4, bank q,
   +bin velayg, start depth, start vel, units, units2, units3,
   +corr e, corr n, dist
    integer ic, ic2, ic3, num ens, ens num, id
    character*70 label1, label2, adoptile, nav file
    ic ()
    ic2 - 1
    ic3 - 0
    total4 = 0
    call velocity(units, units2, units3, num ens, line grad, bin size,
    +blank depth, adep file, nav file)
    close (1)
    open (1, file 'velocity.dat', status - 'old')
    open (2, file = 'gpscorrq.out', status = 'unknown')
    read(1, '(a70)') label1
    write(2, *) label1
    read(1, '(a70)') label2
    write(2, *) label2
    read(1, *)
```

case(2)

```
call clearscreen
    write(*, *) 'PLEASE ENTER A POWER LAW CO-EFFICIENT'
   write (*, *)
   read *, power coeff
   call clearscreen
   write (2, *) 'top layer discharge estimation method: power'
   write (2, *) 'power co-efficient =', power_coeff'
   write (2, *) 'ensemble, dist, easting, northing, width, depth, bin
   + q, top q, btm q, total q'
   write (2, *) 'power co-efficient =', power coeff
   depth bin(0) = blank depth - bin size/2
  10 continue
   total1 = 0
   total2 = 0
   total3 = 0
 20 continue
   ic = ic + 1
   read (1, *, err=30, end=30) id, ens num, dist, corr e,
   +corr_n, corr_w, depth avg, depth bin(ic), vel mag(ic),
   +vel diru(ic), c vel(ic), n vel(ic), z vel(ic), error vel(ic),
   +db_avg(ic), adep_range(ic)
   if (id .eq. ic2) then
     goto 20
    endif
    do k=1, 2
     backspace (1)
    enddo
    read (1, *, err-30, end=30) id, ens num, dist, corr e, corr n,
   tcorr w, depth avg
c 'a()' is equal to the 'non-adep' parameters in the power law equation
  30 continue
    ic ic - 1
    line dirn -((atan(1/line grad)) * 180/3.14159) + 90
    do 40, k=1, ic
     bin vel(k) = vel mag(k)*cos((line dirn-vel dirn(k))*3.14159/180)
     bin q(k) = bin vel(k)*corr w*(depth bin(k) - depth bin(k-1))
     a(k) = bin_vel(k)/('depth_avg - depth_bin(k))**power_coeff)
     totall = bin q(k) + totall
     total2 = a(k) + total2
     total3 = bin vel(k) + total3
  40 continue
```

```
ie3 = ie3 + 1
  total bing = total |
  a avg = total2/ic
  bin velavg - total3/ic
  toplayer q = corr w * blank depth * a avg *
 +((depth avg - blank depth/2)**power coeff)
  btmlayer q = a avg * (((depth avg -
 +adep range(ic))**7)/2)**power coeff)*corr w
  ensemble q = total binq + toplayer q + btmlayer q
  write (2, 100) ens num, dist, corr e, corr n,
 +corr w, depth avg, total bing, toplayer q,
  +btmlayer q, ensemble_q, a_avg
100 format (i5, f8.2, 2f13.2, 7f10.2)
  if (ic2 .eq. 1) then
   start depth = depth avg
   start vel = total3/ic
  endif
  total4
           ensemble q + total4
  if (ic3 .eq. num ens) then
   goto 50
  endif
  ic = 0
  ic2 - ic2
  goto 10
50 continue
  end depth = depth avg
  end vel: bin velavg
  call nearshore(bank q, start depth, start vel, end depth, end vel,
  tunits)
  call clearscreen
  total4 = bank q + total4
  if (units .eq. 1.0) then
   write (2, *) 'total discharge : ', total4, '(cumecs)'
    write(*, *) 'TOTAL DISCHARGE - ', total4, '(cumees)'
    do k ~1, 10
     write(*, *)
    enddo
  end if
```

```
if (units .eq. 3.281) then
    write (2, *) 'total discharge = ', total4, '(cfs)'
    write(*, *) 'TOTAL DISCHARGE = ', total4, '(cfs)'
    do k=1, 10
      write(*, *)
    enddo
   end if
 60 continue
   end
c a subroutine for calculating discharge using the constant method
e a power law fit is still used for the near-bed discharge, as such
e 'discharge2' is very similar to 'discharge1'
   subroutine discharge2(units, units2, units3, adep file, nav file)
   real depth bin(100), vel mag(100), vel dirn(100), corr w,
   +e vel(100), n vel(100), z vel(100), db avg(100), depth avg,
   terror vel(100), total bing, toplayer q, btmlayer q,
   +a avg ensemble q, line grad, blank depth, a(100),
   +power coeff, bin vel(100), bin q(100), adep range(100),
   bin size, line dirn, total1, total2, total3, total4, bank q,
   +bin_velavg, vel_top, start_depth, start_vel, units, units2,
   +units3, corr e, corr n, dist
    integer ic, ic2, ic3, num ens, ens num, id
    character*70 label1, label2, adep file, nav file
    ic = 0
    ic2 1
    ic3 0
    total4 = 0
    call velocity(units, units2, units3, num ens, line grad, bin size,
    blank depth, adep file, nav file)
    close (1)
    open (1, file - 'velocity dat', status - 'old')
    open (2, file - 'gpscorrq.out', status - 'unknown')
    read(1, '(a70)') label1
    write(2, *) label1
    read(1, '(a70)') label2
```

```
write(2, *) label2
 read(1, *)
 depth_bin(0) = blank depth - bin size/2
 call clearscreen
 write(*, *) 'Please enter a power law co-efficient '
 write (*, *)
 read *, power coeff
 call clearscreen
 write (2, *) 'top layer discharge estimation method: constant'
 write (2, *) 'power coefficient for bottom layer =', power coeff
 write (2, *) 'ensemble, dist, easting, northing, width, depth, bin
 + q, top q, btm q, total q'
10 continue
 total1 = 0
 total2 = 0
 total3 = 0
20 continue
 ic = ic + 1
 read (1, *, err=30, end=30) id, ens num, dist, corr e, corr n,
 +corr w, depth_avg, depth_bin(ic), vel_mag(ic), vel_dirn(ic),
 +e vel(ic), n_vel(ic), z_vel(ic), error_vel(ic), db_avg(ic),
 +adcp range(ic)
 if (id .eq. ic2) then
   goto 20
  endif
  do k=1, 2
   backspace (1)
  enddo
  read (1, *, err=30, end=30) id, ens num, dist, corr e, corr n,
 corr w, depth avg
30 continue
  ic - ic - 1
  line dirn = ((atan(1/line grad))*180/3.14159) + 90
  do 40, k-1, ic
   bin vel(k) = vel_mag(k)*cos((line_dirn-vel_dirn(k))*3.14159/180)
   bin q(k) = bin vel(k) * corr w * (depth bin(k)-depth bin(k-1))
   a(k) = bin vel(k)/((depth avg - depth bin(k))**power coeff)
   total1 = bin q(k) + total1
   total2 = a(k) + total2
   total3 = bin vel(k) + total3
40 continue
```

```
vel top = vel mag(1)*cos((line dirn - vel dirn(1))*3.14159/180)
  ic3 = ic3 + 1
  total bing = total1
  a avg = total2/ic
  bin velavg = total3/ic
  toplayer q = corr w * blank depth * vel top
  btmlayer q = a avg * ((((depth_avg -
 +adcp_range(ic))**7)/2)**power_coeff) * corr_w
  ensemble q = total binq + toplayer q + btmlayer q
  write (2, 100) ens num, dist, corr e, corr n, corr w, depth avg,
 +total bing, toplayer q, btmlayer q, ensemble q, a avg
100 format (i5, f8.2, 2f13.2, 7f10.2)
  if (ic2 .eq. 1) then
   start depth = depth avg
   start vel = total3/ic
  endif
  total4 = ensemble q + total4
  if (ic3 .eq. num ens) then
   goto 50
  endif
  ic = 0
  ic2 = ic2 + 1
  goto 10
50 continue
  end depth = depth avg
  end vel = bin velavg
  call nearshore(bank_q, start_depth, start_vel, end_depth, end_vel,
  +units)
  call clearscreen
   total4 = bank q + total4
   if (urits .eq. 1.0) then
    write (2, *) 'total discharge = ', total4, '(cumecs)'
    write(*, *) 'TOTAL DISCHARGE = ', total4, '(cumecs)'
    do k=1, 10
     write(*, *)
    enddo
   en. if
```

```
if (units .eq. 3.281) then
    write (2, *) 'total discharge = ', total4, '(cfs)'
    write(*, *) 'TOTAL DISCHARGE = ', total4, '(cfs)'
    do k=1, 10
      write(*, *)
    enddo
   end if
 60 continue
   end
c a subroutine used to calculate the missing discharge, if any, at the
c start and end of a transect
   subroutine nearshore(bank q, start depth, start vel, end depth,
   +end vel, units)
   real bank q, start dist, end dist, start q, end q, start depth,
   +start_vel, end depth, end vel, units
   integer option3
    call clearscreen
 05 continue
    write(*, *) 'NEAR SHORE DISCHARGE OPTIONS...'
    write(*, *)
    write(*, *) '(1) CALCULATE near shore discharges'
    write(*, *)
    write(*, *) '(2) DO NOT CALCULATE near shore discharges'
    write(*, *)
    write(*, *) 'please enter an option number'
    read *, option3
    select case(option3)
     case(1)
      goto 10
     case(2)
      goto 20
     case default
       call clearscreen
       write (*, *) 'please re-enter option number'
       goto 05
    end select
```

10 continue

```
call clearscreen
```

```
if (units .eq. 1.0) then
 write(*, *) 'enter distance to bank at START of transect (m)'
 read *, start dist
 write(*, *)
 write(*, *) 'enter distance to bank at END of transect (m)'
 read *, end dist
 end if
 if (units .eq. 3.281) then
  write(*, *) 'enter distance to bank at START of transect (ft)'
  read *, start dist
  write(*, *)
  write(*, *) 'enter distance to bank at END of transect (ft)'
  read *, end_dist
 end if
 call clearscreen
 start q = 0.707 * start depth * start dist * start vel/2
 end q - 0.707 * end depth * end_dist * end_vel/2
 bank q = start q + end q
 goto 30
20 continue
 bank q = 0
30 continue
 end
```

subroutine velocity(units, units2, units3, num_ens, line_grad, +bin_size, blank_depth, adop_file, nav_file)

c a subroutine for combining the vessel velocity and the adep measured c water velocities

real depth(100), mag_adcp(100), dirn_adcp(100), e_adcp(100), +n_adcp(100), z_adcp(100), error_vel(100), db_1(100), db_2(100), +db_3(100), db_4(100), per_good(100), e_boat, n_boat, corr_c, +corr_n, corr_w, depth_avg, dist, e_water(100), n_water(100), +z_water(100), mag_water(100), dirn_water(100), db_avg(100), +junk1(100), junk2(100), junk3(100), line_grad, bin_size,

```
+adep angle, adep range, bin ratio, blank depth, mag deeln,
 +blank dist, units, units2, units3, junk4
 integer ens num, good bins, numbins, ensemblenum, num ens, ic,
 +ic2, error, error2, error3, option1
 character*70 label1, label2, adop file, nav file
 ic2 = 0
  call clearscreen
05 continue
  write(*, *) 'DEPTH CALCULATION OPTIONS...'
  write(*, *) '(1) use ADCP beam depths'
  write(*, *)
  write(*, *) '(2) use FATHOMETER data'
  do j=1, 10
   write(*, *)
  enddo
  write(*, *) 'please enter an option number'
  read *, option1
  select case (option1)
    case (1)
     call ens header1(units, num ens, line grad, nav file)
     call ens header2(units, num ens, line grad, nav file)
    case default
     call clearscreen
     write (*, *) 'please re-enter option number'
     goto 05
  end select
  rewind (3)
  open (1, file = 'velocity.dat', status = 'unknown')
  open (4, file = adep_file, status = 'old')
  call clearscreen
  write(*, *) 'please enter ADCP BEAM ANGLE (deg)'
  write (*, *)
  read *, adop angle
  call clearscreen
   write(*, *) 'if NOT already corrected...'
   write(*, *) 'please enter the local magnetic declination (deg)'
   write (*, *)
```

```
read *, mag decln
  call clearscreen
  read(4, '(a70)') label 1
  read(4, '(a70)') label2
  write(1, *) label1
  write(1, *) label2
  write(1, 100) 'id, ens, dist, east, north, width, depth, bin, vel
 +mag, vel dirn, east vel, north vel, vert vel, error vel, db avg, a
 +dcp range'
100 format(a120)
  read(4, *, err=80, end=95, iostat=error) bin_size, junk4,
 +adcp depth
  bin size = (bin size/100) * units
  adep depth = (adep depth/100) * units
10 continue
  ic = 0
20 continue
  ic2 = ic2 + 1
  read (4, *, en=80, end=95, iostat=error) (junk1(i), i=1, 7),
 +ensemblenum, (junk2(i), i=1, 13), depth b1, depth b2, depth b3,
 +depth b4, (junk3(i), i=1, 19), numbins
  depth avg = (depth b1 + depth b2 + depth b3 + depth b4)/4
  depth avg = depth avg * units2
30 continue
  if (option1.eq. 1) then
   read (3, *, err=85, end-95, iostat error2) ens num, dist,
  + corr_e, corr_n, corr_w, e_boat, n_boat
  endif
  if (option1 .eq. 2) then
   read (3, *, err=85, end=95, iostat=error2) ens num, dist,
  + corr e, corr n, corr w, e boat, n boat, depth avg
  endif
  if (ens num .lt. ensemblenum) then
   goto 30
  endif
40 continue
  ic = ic + 1
  read (4, *, end=50, err=90, iostat=error3) depth(ic),
  +mag_adep(ic), dirn adep(ic), e adep(ie), n adep(ic), z adep(ie),
```

```
terror vel(ic), db 1(ic), db 2(ic), db 3(ic), db 4(ic),
 +per good(ic)
 if (ic.ge. numbins) goto 50
 goto 40
50 continue
 if (ens num .gt. ensemblenum) then
   goto 20
 endif
  do j-1, ic
   depth(j) = depth(j) * units2
   mag adep(j) = mag adep(j) * units2 * units3
   dirn adep(j) = dirn adep(j) - mag deeln
   if(dirn adep(j).gt. 360) then
     dirn adep(j) = dirn adep(j) = 360
   endif
   z = adep(j) = z = adep(j) * units2 * units3
   error vel(j) = error vel(j) * units2 * units3
  enddo
  do 60, k=1, ic
   e adep(k) = mag adep(k) * sin((dirn adep(k))*3.14159/180)
   n adep(k) = mag adep(k) * cos((dirn adep(k))*3.14159/180)
   e water(k) = e boat \pm e adep(k)
   n water(k) =n boat +n adep(k)
   z water(k) = z adep(k)
   mag water(k) = (e \text{ water}(k)^{**}2 + n \text{ water}(k)^{**}2)^{**}0.5
   dirn water(k) = (a\cos(n \text{ water(k)/mag water(k)}))*180/3.14159
   db avg(k) = (db - 1(k) + db - 2(k) + db - 3(k) + db - 4(k))/4
60 continue
  adep_range = (depth_avg = adep_depth)*(eos((adep_angle)*
  +3.14159/180) + adep_depth
  blank dist depth(1) - bin size/2 - adep depth
  blank depth - adep depth + blank dist
  bin range adep range - blank depth
  bin ratio bin range/bin size
  good bins = aint(bin ratio)
  do 70, k 1, good bins
   if (mag water(k) .gt. 95) then
     goto 70
   endif
    write (1, 200) ic2, ens num, dist, corr e, corr n, corr w,
  1 depth avg, depth(k), mag water(k), dirn water(k), e water(k),
  + n water(k), z water(k), error vel(k), db avg(k), adep range
 70 continue
```

```
200 format (2i5, f8,2, 2f13,2, 11f10.2)
   goto 10
 80 continue
   if (error ,ne. 0) then
    write(*, *) 'error in adop header, ensemble no.', ic2
   endif
 85 continue
   if (error2 .ne. 0) then
    write(*, *) 'error in navfile, ensemble no.', ic2
    stop
   endif
 90 continue
   if (error3 .gt. 0) then
     write(*, *) 'error in adep bin data, ensemble no.', ie2
     stop
   endif
 95 continue
   end
   subroutine ens header1(units, num_ens, line_grad, nav_file)
c a subroutine for calculating the survey line definintion, corrected
c ensemble positions and widths, and vessel velocities
    real e end(100), n end(100), e vel, n vel, e start, n start,
   +line grad, line int, corr e, corr n, corr w, sum e,
   +sum esq, sum n, sum en, corr estart, corr nstart, last e, last n,
   +corr eavg, corr navg, units, dist
    integer ic, ens num(100), num ens, time(100), time start
    character*70 nav file
    sum e = 0
    sum esq = 0
    sum n=0
    sum en = 0
    last e 0
    last n = 0
    ic = 0
```

```
call read gps1(num ens, time start, e start n start, time,
  +ens num, e end, n end, nav file)
    open (3, status = 'scratch')
    sum e = e start + sum e
    sum esq = e start**2 + sum esq
    sum n = n start + sum n
    sum en = e start*n start + sum en
    ic = num ens + ic
    do 10 j=1, ic
        sum e = sum_e + c end(j)
        sum esq = sum_esq + e_end(j)**2
        sum n = sum n + n end(i)
        sum_en = sum_en + e_end(j)*n_end(j)
10 continue
    ic - ic + 1
     line grad = (ic*sum en - sum c*sum n)/(ic*sum esq - sum e**2)
     line int = (sum esq*sum n - sum e*sum en)/(ic*sum esq - sum e**2)
     ic = ic - 1
     e vel = (e end(1) - e start)*units/(time(1) - time start)
     n_vel = (n_vel = (n_vel = (1) - n_vel = (1) - time_vel 
     corr_estart = (line_grad*n_start + e_start - line_grad*line_int)
    +/(line grad**2+1)
     corr nstart = line grad*corr estart + line int
     corr e = (line grad*n end(1) + e end(1) - line grad*line int)
    +/(line grad**2 + 1)
     corr n = line grad*corr e + line int
     corr \mathbf{w} = (((\text{corr } \mathbf{e} - \text{corr } \text{estart})^{**}2 + (\text{corr } \mathbf{n} - \text{corr } \text{nstart})^{**}2)
    +**0.5)*units
     dist = corr w/2
      corr eavg = (corr estart + corr e)/2
      corr_navg = (corr_nstart + corr_n)/2
      write(3, *) ens num(1), dist, corr eavg, corr navg, corr w, e vel,
     +n_vel
      last e = corr e
      last n = corr n
       do 20, j=2, ic
```

```
n_j vel = (n_j end(J) - n_j end(J-1))*units/(time(J) - time(j-1))
     corr e = (line grad*n end(j) + e end(j) - line grad*line int)
   \pm /(line grad**2 ± 1)
     corr_n - line grad*corr e + line int
     corr w = (((corr e - last e)^{**2} + (corr n - last n)^{**2})^{**0.5})^{*}
   + units
     dist = (((corr e - corr estart)**2 + (corr n - corr nstart)**2)
   + **0.5)*units - corr w/2
     corr_eavg = (corr_e + last_e)/2
     corr_navg = (corr_n + last_n)/2
     write (3, *) ens num(j), dist, corr eavg, corr navg, corr w,
   Legvel, n vel
     last e corr e
     last n = corr n
 20 continue
   end
   subroutine ens header2(units, num ens, line grad, nav file)
c a subroutine for calculating the survey line definintion, corrected
c ensemble positions, widths, depths and vessel velocities
   real e end(100), n end(100), e vel, n vel, e start, n start,
   Hine grad, line int, corr e, corr n, corr w, sum e,
   sum esq, sum n, sum en, corr estart, corr nstart, last e, last n,
   feorr eavg, corr navg, units, dist, depth avg(100)
   integer ic, ens num(100), num ens, time(100), time start
    character*70 nav file
    sum e 0
    sum esq = 0
    sum n 0
    sum en = 0
    last e = 0
    last n = 0
    ie - 0
```

e vel = (e end(i) - e end(i-1))*units/(time(i) - time(i-1))

```
call read gps2(num ens, time start, e start, n start, time,
 tens num, e end, n end, depth avg, nav file)
 open (3, status 'scratch')
 sum e e start i sum e
 sum esq e start**2 + sum esq
 sum n n start i sum n
 sum en " e start*n start + sum en
 ic = num ens + ic
 do 10 j 1, ic
  sum e + e - end(j)
  sum esq = sum esq + e end(j)**2
  sum n + n end(j)
  sum en sum en + e end(j)*n end(j)
10 continue
 ic ic 4.1
 line grad (ie*sum en - sum e*sum n)/(ie*sum esq - sum e**2)
 line int (sum esq*sum n - sum e*sum en)/(ic*sum esq - sum e**2)
 ic ic - 1
 do 15, j 1, ic
  depth avg(1) depth avg(j) * units
15 continue
 e vel (e end(1) - e start)*units/(time(1) - time start)
 n vel (n \text{ end}(1) - n \text{ start}) * \text{units}/(\text{time}(1) - \text{time start})
 corr estart (line grad*n start | e start - line grad*line int)
 1/(line_grad**2 + 1)
 corr nstart line grad*corr estart | line int
 corr e (line grad*n end(1) + e end(1) - line grad*line mt)
 \pm/(line grad**2 \pm 1)
 corr n line grad*corr e + line int
 corr w (((corr e - corr estart)**2 + (corr n - corr nstart)**2)
 +**0,5)*units
  dist
      corr w/2
  corr cavg (corr estart + corr e)/2
  corr navg (corr nstart + corr n)/2
  write(3, *) ens num(1), dist, corr eavg, corr navg, corr w, e vel,
```

```
+n vel, depth avg(1)
   last e corr e
   last_n = corr_n
   do 20, j-2, ic
     e vel = (e \text{ end}(j) - e \text{ end}(j-1))*units/(time(j) - time(j-1))
     n \text{ vel} = (n \text{ end}(J) - n \text{ end}(J-1))*units/(time(J) - time(j-1))
     corr e = (line grad*n end(j) + e end(j) - line grad*line int)
   + /(line_grad**2 + 1)
     corr n = line grad*corr e + line int
     corr w = (((corr e - last e)^{**}2 + (corr n - last n)^{**}2)^{**}0.5)^{*}
   + units
     dist = (((corr_e - corr_estart)**2 + (corr_n - corr_nstart)**2)
   + **0.5)*units - corr w/2
     corr eavg = (corr e + last e)/2
     corr navg = (corr n + last n)/2
     write (3, *) ens rum(j), dist, corr eavg, corr navg, corr w,
   + e vel, n vel, depth avg(j)
     last e corr e
     last n = corr n
 20 continue
   end
    subroutine read gps1(ic4, time start, e start, n start,
   tens time, ens num, e end, n end, nav file)
c a subroutine for extracting ensemble data from gps file which
e does not include depth data
    real e start, a start, e end(100), n end(100), gps e(1000),
   +gps_n(1000)
    integer time start, hour start, min start, see start,
   +ens time(100), gps hour(1000), gps min(1000), gps sec(1000), ic,
    tic4, error, ens num(100)
    character*1 chk, nav file*70
```

```
ic = 0
  ic4 = 0
  open (5, file = nav_file, status = old')
01 continue
  read (5, '(a1)') chk
  select case(chk)
   case('E')
     goto 02
   case('e')
     goto 02
   case default
     goto 01
  end select
02 continue
  read (5, 200, err=20, end=20, iostat=error) hour start, min start,
 +sec start, e start, n start
  time_start = hour_start*3600 + min_start*60 + sec_start
  do j - 1, 2
   backspace 5
  enddo
05 continue
  ic4 = ic4 + 1
  read (5, 100, err=40, end-40) ens num(ic4)
 10 continue
  ic = ic + 1
  read (5, 200, err=30, end=30, iostat=error) gps hour(ic),
  +gps min(ic), gps sec(ic), gps e(ic), gps n(ic)
  goto 10
100 format(10x, i4)
200 format(i2, 1x, i2, 1x, i2, f12.2, f10.2)
20 continue
  if (error .ne. 0) then
   write(*, *) 'error in gps data'
    stop
  endif
30 continue
  if (error .ne. 0) then
   ic ic 2
    ens_time(ic4) - gps_hour(ic)*3600 + gps_min(ic)*60 + gps_sec(ic)
```

```
if(ens_time(ic4)_eq. 0) then
      e \text{ end(ic4-1)} = e \text{ end(ic4-1)} + (e \text{ end(ic4-1)} - e \text{ end(ic4-2)})
      n = nd(ic4) = n = nd(ic4-1) + (n = nd(ic4-1) - n = nd(ic4-2))
      ens time(ic4) -2*ens time(ic4-1) - ens time(ic4-2)
      write(*, *) 'error at ens num', ens num(ic4)
      read(*, *)
      ic4 ic4 + 1
      goto 40
     endif
     e end(ic4) = gps e(ic)
     n_end(ic4) = gps_n(ic)
     backspace 5
     goto 05
    endif
 40 continue
   ic4 ic4 - 1
    end
    subroutine read gps2(ic4, time start, e start, n start,
   tens time, ens num, e_end, n_end, depth_avg, nav_file)
c a subroutine for extracting ensemble data from gps file which includes
c depth data
    real e start, n start, e end(100), n end(100), gps e(1000),
   +gps n(1000), depth total, depth avg(100), depth(1000)
    integer time start, hour start, min start, see start,
   +ens time(100), gps hour(1000), gps min(1000), gps sec(1000), ic,
   tic2, ic3, ic4, error, ens num(100)
    character*1 chk, nav file*70
    ic 0
    ic2 = 0
    ic3 0
    ic4 0
    open (5, file nav file, status dold')
  01 continue
    read (5, '(a1)') chk
    select case(chk)
     case('E')
```

```
goto 02
   case('e')
    goto 02
   case default
    goto 01
  end select
02 continue
  ie2 = ie2 + 1
  read (5, 200, err=20, end=20, iostat=error) hour start, min start,
 +sec_start, n_start, e_start
  time_start = hour_start*3600 + min_start*60 + sec_start
  do j=1, 2
   backspace 5
  enddo
05 continue
  ic4 = ic4 + 1
  read (5, 100, err=40, end=40) ens num(ic4)
10 continue
  ic = ic + 1
  read (5, 200, err=30, end=30, iostat=error) gps hour(ic),
  gps_min(ic), gps_sec(ic), gps_n(ic), gps_e(ic), depth(ic)
  goto 10
100 format(10x, i4)
200 format(i2, 1x, i2, 1x, i2, f12,2, f10,2, f10,2)
20 continue
  if (error .ne. 0) then
   write(*, *) 'error in gps data'
   stop
  endif
30 continue
  if (error .ne. 0) then
   ic = ic - 2
   depth total = 0
    do j=ic2, ic
    depth total = depth(j) + depth total
    ic3 = ic3 + 1
    enddo
    depth avg(ic4) = depth total/ic3
    ens_time(ic4) = gps hour(ic)*3600 + gps min(ic)*60 + gps sec(ic)
```

```
e end(ic4) gps_e(ic)
  n end(ic4) = gps_n(ic)
  ic2 = ic + 1
  ic3 = 0
  backspace 5
  goto 05
 endif
40 continue
 ic4 = ic4 - 1
 end
 subroutine clearscreen
 do k=1, 25
   write(*, *)
 enddo
 end
              }---<<..THE.END..>>---{
```

APPENDIX C

ADCPFILL SOURCE CODE

```
real bdepth1(10), bdepth2(10), bdepth3(10), heada 1(20),
+heada 2(20), heada 3(20), headb 1(30), headb 2(30), headb 3(30),
+topbtm1(10), topbtm2(10), topbtm3(10)
 real depth1(100), depth2(100), depth3(100), vel mag1(100),
+vel mag2(100), vel mag3(100), vel dirn1(100), vel dirn2(100),
+vel_dirn3(100), east_vel1(100), east_vel2(100), east_vel3(100),
+north_vel1(100), north_vel2(100), north_vel3(100), vert_vel1(100),
+vert vel2(100), vert vel3(100), error vel1(100), error vel2(100),
+error vel3(100), db 11(100), db 12(100), db 13(100), db 21(100),
+db 22(100), last bing, q diff,
+db 23(100), db 31(100), db 32(100), db 33(100), db 41(100),
+db 42(100), db 43(100), discharge1(100), discharge2(100),
+discharge3(100), last t, dt, bin size, units, e total,
+n total, bin total, 1 total, de, dn, dl, dbin q, dtop q, dbtm q
 integer time1(10), time2(10), time3(10), ens num1, ens num2,
+ens num3, ic, ic2, ic3, ic4, num bins, per good1(100),
 +per good2(100), per good3(100)
 character*70 label1, label2, label3, label4*50, file_name, ft_em*1
 ic = 0
 ic2 = 0
 last bing = 1
 last top = 0
 last btm - 0
 de = 0
 dn 0
 dl = 0
 dbin q = 0
 dtop q = 0
 dbtm q = 0
 call clearscreen
 write(*, *) '
                         Welcome to ADCPFILL for DOS'
 do k~1, 10
  write(*, *)
 enddo
 write(*, *) 'press ENTER to continue'
 read(*,*)
05 continue
 cali clearscreen
 write(*, *) 'please enter adep ascii file name and path'
 read(*, '(a50)', end-05, err 05) file name
```

```
call clearscreen
  write(*, *) 'please wait while ADCPFILL checks...'
  write(*, *) '
                           ', file name
  do k=1, 10
  write(*, *)
  enddo
  open(1, file = file name, status = 'old')
  open(2, file = 'clean.out', status = 'unknown')
  open(3, status = 'scratch')
  read(1, '(a70)', end=90, err=90) label1
  write(2, *) label 1
  read(1, '(a70)', end=90, err=90) label2
  write(2, *) label2
  read(1, *) bin size
  backspace 1
  read(1, '(a70)', end=90, err=90) label3
  write(2, *) label3
10 continue
  read(1, *, end=90, err=90) (time1(i), i=1, 7),
 +ens num1, (heada 1(i), i=1, 13), (bdepth1(i), i=1, 4),
 +(\text{headb } 1(i), i=1, 19), \text{ num bins}
  backspace 1
  read(1, 100, end=90, err=90) ft cm
100 format(3x, a1)
  select case(ft cm)
   case('f')
   units = 3.281
   case('c')
   units = 1.0
  endselect
  backspace 1
  read(1, '(a50)', end=90, err=90) label4
  if (bdepth1(1).lt, 1.0) then
    bdepth1(1) = (bdepth1(2) + bdepth1(3) + bdepth1(4))/3
  endif
  if (bdepth1(2) .lt. 1.0) then
    bdepth1(2) = (bdepth1(1) + bdepth1(3) + bdepth1(4))/3
  endif
  if (bdepth1(3) .lt. 1.0) then
    bdepth1(3) = (bdepth1(1) + bdepth1(2) + bdepth1(4))/3
  endif
  if (bdepth1(4) .lt. 1.0) then
```

```
bdepth1(4) = (bdepth1(1) + bdepth1(2) + bdepth1(3))/3
  endif
  last t = \text{headb } 1(2)
20 continue
  ic = ic + 1
  read(1, *, end=90, err=90) depth1(ic), vel mag1(ic),
 +vel dirn1(ic), east vel1(ic), north vel1(ic), vert vel1(ic),
 +error vel1(ic), db 11(ic), db 21(ic), db 31(ic), db 41(ic),
 +per good1(ic), discharge1(ic)
  if(ic .ge. num bins) goto 30
  goto 20
30 continue
  q diff = headb 1(11) - last bing
  if(q diff.eq. 0) then
   ic = 0
   goto 10
  endif
  ic = ic - 1
35 continue
  write(2, 200) (time1(i), i=1, 7), ens_num1, (heada_1(i), i=1, 13),
  +(bdepth1(i), i=1, 4), (headb 1(i), i=1, 19), label4
  do k=1, num bins
   write(2, 300)depth1(k), vel mag1(k), vel dirn1(k), east vel1(k),
 + north vell(k), vert vell(k), error vell(k), db 11(k), db 21(k),
  + db 31(k), db 41(k), per good1(k), discharge1(k)
  enddo
200 format(7i4, i6, 5f8.2, /, 8f10.2, 4f7.2, /, 5f10.2, /, 5f10.2, /,
  \pm 3f14.2, 6f8.2, /, a50)
300 format(f9.1, f11.2, f11.3, 8f9.1, i7, f13.2)
  rewind (3)
40 continue
  last bing = headb 1(11)
  topbtm1(1) = headb 1(12) - last top
  topbtm1(2) = headb 1(13) - last btm
  last top = headb 1(12)
  last btm = headb 1(13)
  read(1, *, end=90, err=90) (time2(i), i=1, 7),
  +ens num2, (heada 2(i), i=1, 13), (bdepth2(i), i=1, 4),
  +(\text{headb } 2(i), i=1, 19), \text{ num bins}
   if (bdepth2(1).lt. 1.0) then
     bdepth2(1) = (bdepth2(2) + bdepth2(3) + bdepth2(4))/3
```

```
endif
  if (bdepth2(2) .lt. 1.0) then
   bdepth2(2) = (bdepth2(1) + bdepth2(3) + bdepth2(4))/3
  endif
  if (bdepth2(3) .lt. 1.0) then
   bdepth2(3) = (bdepth2(1) + bdepth2(2) + bdepth2(4))/3
  endif
  if (bdepth2(4) .lt. 1.0) then
   bdepth2(4) = (bdepth2(1) + bdepth2(2) + bdepth2(3))/3
  endif
  q diff headb 2(11) - last bing + dbin q
  if(q diff .ne. 0) then
   goto 60
  endif
  ic2 ic2 | 1
  dt = headb 2(2) - last t
  last t headb 2(2)
  write(3, *) (time2(i), i=1, 7), headb=2(2), dt
  do 50, k=1, num bins
   read(1, 400, end 90, err 90)
50 continue
400 format(70x)
  goto 40
60 continue
  if(ic2 .gt. 0) goto 70
  time1 time2
  ens num l
              ens num2
  heada 1
            heada 2
  bdepth1 bdepth2
  headb 1 headb 2
  last t headb 1(2)
  headb 1(1) headb 1(1) + dl
  headb 1(3) headb 1(3) ± dn
  headb 1(4) headb 1(4) + de
  headb 1(5) (headb 1(3)**2 + headb 1(4)**2)**0.5
  headb 1(11) - headb 1(11) + dbin q
  headb 1(12) headb 1(12) thdtop q
  headb 1(13) headb 1(13) | dbtm q
  ic ()
```

Ü

```
70 continue
 call clearscreen
 ic = 0
 bin total = headb 1(11)
 n total headb 1(3)
 e total = headb 1(4)
 1 total = headb 1(1)
 topbtm2(1) = headb \ 2(12) - headb \ 1(12)
 topbim2(2) = headb 2(13) - headb 1(13)
 rewind (3)
80 continue
 ic = ic + 1
 read(1, *, end=90, err=90) depth2(ic), vel mag2(ic),
 +vel_dirn2(ic), east_vel2(ic), north_vel2(ic), vert_vel2(ic),
 terror vel2(ic), db 12(ic), db 22(ic), db 32(ic), db 42(ic),
 +per good2(ic), discharge2(ic)
 if(ic.lt. num bins) then
   goto 80
 endif
 ic3 = ic2
 ic4 1
 do 85 k=1, ic2
 topbtm3 (topbtm1*ic3 + topbtm2*ic4)/(ic3+ic4)
 ens num3 = (ens num1*ic3 + ens num2*ic4)/(ic3+ic4)
 heada 3 (heada 1*ic3 + heada <math>2*ic4)/(ic3+ic4)
 bdepth? = (bdepth1*ic3 + bdepth2*ic4)/(ic3+ic4)
 headb + (headb 1*ic3 + headb <math>2*ic4)/(ic3+ic4)
 depth3 depth1
 vel mag3 = (vel mag1*ic3 \pm vel mag2*ic4)/(ic3\pmic4)
 vel dirn3 (vel dirn1*ic3 + vel dirn2*ic4)/(ic3+ic4)
 east vel3 (east vel1*ic3 + east vel2*ic4)/(ic3+ic4)
 north vel3 = (north vel1*ic3 + north vel2*ic4)/(ic3+ic4)
 vert vel3 = (vert vel1*ic3 + vert vel2*ic4)/(ic3+ic4)
 error vel3 = (error vel1*ic3 + error vel2*ic4)/(ic3+ic4)
 db 13 (db 11*ie3 + db 12*ie4)/(ie3+ie4)
  db 23 - (db 21*ic3 + db 22*ic4)/(ic3+ic4)
  db_33 = (db_31*ic_3 + db_32*ic_4)/(ic_3+ic_4)
 db 43 = (db \ 41*ic3 + db \ 42*ic4)/(ic3+ic4)
  per good3 = (per good1*ic3 + per good2*ic4)/(ic3+ic4)
  read(3, *) (time3(ik), ik=1, 7), headb 3(2), dt
  bin q = 0
  do i 1, num bins
  discharge3(i) \sim ((heada 3(6)*north vel3(i))-(heada 3(7)*
 + east vel3(i)))*(bin size/100)*units*dt
```

```
if(abs(discharg: 3(i)).lt. 10000) then
   bin q discharge3(i) + bin q
  endif
  enddo
  headb 3(11) = bin q + bin total
  headb 3(3) = \text{heada } 3(7) * \text{dt} + \text{n total}
  headb 3(4) = heada 3(6) * dt + e total
  headb 3(5) = (\text{headb } 3(3)**2 + \text{headb } 3(4)**2)**0.5
 headb 3(1) = ((heada 3(7)*dt)**2 + (heada 3(6)*dt)**2)
 +**0.5 + 1 total
 headb_3(12) = topbtm3(1) + last_top
 headb 3(13) = \text{topbtm}3(2) + \text{last btm}
  write(2, 200) (time3(i), i=1, 7), ens num3, (heada 3(i), i=1, 13),
 +(bdepth3(i), i=1, 4), (headb 3(i), i=1, 19), label4
  do j=1, num bins
  write(2, 300) depth3(j), vel mag3(j), vel_dirr3(j), east_vel3(j),
 + north_vel3(j), vert_vel3(j), error_vel3(j), db_13(j), db_23(j),
 + db 33(j), db 43(j), per good3(j), discharge3(j)
  enddo
 ie3 = ie3 - 1
  ic4 - ic4 + 1
  print *, 'ensemble no. ',ens num3,' has been fixed'
 1 \text{ total} = \text{headb } 3(1)
  n \text{ total} = \text{headb } 3(3)
  e_{total} = headb 3(4)
  bin total = headb_3(11)
  last top = headb 3(12)
  last btm = headb_3(13)
85 continue
  dl = 1 total - headb 1(1)
  dn = n \text{ total - headb } 1(3)
  de = e total - headb 1(4)
  dbin q = bin total - headb 1(11)
  dtop q = headb 3(12) - headb 1(12)
  dbtm_q = headb 3(13) - headb 1(13)
  headb 2(1) = \text{headb } 2(1) + \text{dl}
  headb 2(3) = headb 2(3) + dn
  headb 2(4) = headb 2(4) + de
  headb 2(5) = (\text{headb } 2(3)**2 + \text{headb } 2(4)**2)**0.5
  headb 2(11) = headb 2(11) + dbin q
  headb 2(12) = headb 2(12) + dtop q
  headb_2(13) = headb_2(13) + dbtm_q
  time1 = time2
  cns num1 = ens num2
  heada 1 = heada 2
  bdepth1 = bdepth2
```

```
headb_1 headb_2
 depth1 depth2
 vel mag1 vel mag2
 vel dirn1 vel dirn2
 east_vel1 | east_vel2
 north_vel1 north_vel2
 vert_vel1 vert_vel2
 error vel1 error vel2
 db 11
        db 12
        db_22
 db 21
 db 31 db 32
 db 41 db 42
 per good1 per good2
 discharge1 discharge2
 last_t headb 1(2)
 ic2 0
 goto 35
90 continue
 end
```

subroutine clearscreen do k=1, 25 write(*, *) enddo end

APPENDIX D

GPSQ Version 1.0: User Manual

INTRODUCTION

This manual describes version 1 of a program designed to utilise data from an external Differential Global Positioning System to re-calculate river discharges measured using an RDI instruments ADCP.

The source code for the computer program is written in FORTRAN and is listed in Appendix B. An executable version of the code is contained on a MS-DOS formatted disk, labelled "GPSQ Ver 1.0". The program will run on most IBM compatible P.C.s. This program may be freely copied, but the source code may not be distributed to other parties. The author accepts no responsibility or liability resulting from the use of the program.

INSTALLATION

To install GPSQ ver 1.0 onto your hard drive, insert the diskette provided into the a: drive of your machine and type a:\install. A directory named GPSQ will then be created on your hard drive, the program files will then be copied into this directory.

RUNNING THE PROGRAM

Run the program by typing GPSQ at the command prompt in the GPSQ directory. A title screen should then be displayed, press ENTER to continue. The program then runs through the following stages:

(1) The user is prompted for the name of the ADCP and Navigation (GPS) data files, if the files are not in the current directory then a path must be specified. Sample data files; ADCP.DAT and GPS.DAT, are contained on the installation disk.

- The user is asked to input a name for the final discharge data output file. If no path is specified, the file is put placed in the current directory.
- (3) A menu is displayed on the screen, giving options for data output units, choose from either English units (ft, ft/s, cfs) or SI units (m, m/s, cumecs).
- (4) A second menu is displayed, asking the user to input a choice for the method to be used for top layer velocity estimation, either "power" or "constant".
- (5) A 'depth calculation options' menu is displayed, either ADCP beam depths or FATHOMETER data can be chosen. At present the fathometer depth data option is not available, and if choosen an error message to this affect will appear.
- (6) The program prompts the user for the ADCP beam angle (in degrees). If this information is unknown, it can be determined by pressing F9 in the RDI PLAYBACK program.
- (7) The program asks for the local magnetic declination in degrees, if not already corrected for in the ADCP configuration file.
- (8) A bottom track declination is then displayed on the screen. The bottom track declination is equal to the average directional difference between the bottom track data and GPS data. Hit ENTER to continue
- (9) A power-law co-efficient is then required by the program, a value of 0.1667 is recommended for most applications, for more information see Chen, (1991).
- (10) There is then a short delay whilst the program processes the velocity data. A menu is then displayed asking the user whether or not the require the near shore discharge calculation option.
- (11) The final results of the discharge calculation are then displayed on the screen in terms of total discharge, total area, average velocity.
- (12) During the program two files are created, a velocity data file and discharge data

file. The format of these files are described in the main body of this report.

APPENDIX E

ADCPFILL: User Manual

INTRODUCTION

This manual describes a program designed to fill in missing data from processed ADCP data files, in the RDI TRANSECT program format.

The source code for the computer program is written in FORTRAN and is listed in Appendix C. An executable version of the code is contained on a MS-DOS formatted disk, labelled "ADCPFILL". The program will run on most IBM compatible P.C.s. This program may be freely copied, but the source code may not be distributed to other parties. The author accepts no responsibility or liability resulting from the use of the program.

INSTALLATION

To install ADCPFILL onto your hard drive, insert the diskette provided into the a: drive of your machine and type a:\install. A directory named ADCPFILL will then be created on your hard drive, the program files will then be copied into this directory.

RUNNING THE PROGRAM

Run the program by typing ADCPFILL at the command prompt in the ADCPFILL directory. A title screen should then be displayed, press ENTER to continue. The program then runs through the following stages:

- (1) The user is prompted for the name of the processed ADCP data files, if the files are not in the current directory then a path must be specified.
- (2) The program then processes the ADCP file, checking for bad ensembles. The numbers of any bad ensembles are displayed on the screen at this time.

(3) A new ADCP data file, CLEAN.OUT, with all bad or missing data segments filled in is produced in the current working directory.